



PRODUCT FEATURES

- High quality 1200 lumen white LED, 6500k
- Hard anodized die cast matte aluminium body
- Head rotates to 90° angle
- Useful pocket clip and Super strong magnetic base
- Rubberised easy press side switch
- Flawless smooth reflector for long distance beam
- Memory Switch - Remembers last mode used
- IP65 dust and water resistant
- Impact resistant to 2m
- High quality 2600mAh 18650 Li-ion battery included
- Built-in rubberised USB-C charging port
- Battery level and charging indicator under the switch
- Circuit Protection prevents battery from over-charging or over-discharging
- Fast 1A USB-C charging - 2.5 hour charge time
- High quality 0.5m USB-C charging cable included
- Also works with 2 x CR123A batteries (not included)

BATTERY - 3.6v 2600mAh 18650 Li-ion (included) / or 2 x CR123A batteries (not included)

WEIGHT - 209g (with li-ion battery) / 161g (without battery)

DIMENSIONS - Extended size 160.5 x Ø 30x Ø 27mm

ADVICE & IMPORTANT INFORMATION!

- Do not look directly at LEDs.
- Do not operate in direct sunlight or extreme temperature conditions (below -10°C or above 40°C).
- LEDs can become warm/hot when switched on; DO NOT touch and NEVER place face down on any surface – risk of fire! Even once the device has been switched off, DO NOT place face down as the LED and Lens can stay hot/warm for a while.
- Do not use the device if there is any visible damage.
- Do not use the device in the immediate vicinity of flammable materials or gases.
- Take care when charging, check the charging output on the charging source you are using and DO NOT exceed the stated Max charging input or damage may occur to the battery and may void the warranty.
- The rechargeable battery will reach full performance after a few complete charging and discharging cycles.
- To keep the rechargeable battery in optimum condition, it should be recharged every 3-6 months, especially if it is not being used for a long period of time.
- Always fully charge rechargeable batteries before storage and if the rechargeable battery can be removed, this is advised to avoid battery depletion and avoids the risk of a battery leaking.
- Always protect lithium batteries from heat, intense sunlight, fire, water and moisture – danger of explosion!
- If a battery is damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact occurs, rinse thoroughly with water. If irritation persists, seek medical advice. Seek immediate medical

ANSI FL1 Standard



	1200 Lumen	180 M	3 H
HIGH	1200 Lumen	180 M	3 H
MEDIUM	700 Lumen	100 M	4.5 H
LOW	100 Lumen	20 M	14 H

OPERATING INSTRUCTIONS

SWITCH SEQUENCE:- High > Medium > Low > Off

Memory Switch - If left On in any mode for over 5 seconds, the next press will turn off. Next press On will return to the last mode used.

RECHARGING

- Only use a 5V USB-C charging cable (Max 1A).
- Lift the charging port cover on the side of the light.
- Plug the USB-C end of the cable into the charge port.
- Plug the USB-A end of the cable into a USB charging source (do not exceed 5V-1A charging input or damage may occur. Please do not use "Fast Chargers" as this can over-load the battery).
- Green Flash indicates charging, Solid Green indicates fully charged.
- Charge Time: 2.5 hours
- Make sure the charge port cover is secured back in place.

(THIS PRODUCT CAN NOT BE USED WHILE RECHARGING)

Warranty void if not used with the specified cable & max charge input

CHARGING INDICATOR

- Green Flashing = charging
- Solid Green = fully charged

BATTERY LEVEL INDICATOR

NOTE: Battery indicator only lights up for 10 seconds when the flashlight is first turned on.

- Green = 65% - 100%
- Orange = 30% - 65%
- Red = 5% - 30%
- Red Flashing = less than 5%

- assistance if lithium battery fluid comes into contact with the eyes.
- Children under 12 years of age should only use the product under adult supervision.
- Do not disassemble or attempt to modify the product; this will void the warranty and can be dangerous. Improper use or modification is not covered under the warranty.
- Take care not to let lenses come into contact with hard/sharp objects, damage/scratches to lenses will affect light output.
- Do not use the product in the immediate vicinity of flammable materials or gases.
- Before cleaning the product, disconnect the charge cable. Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.
- This product is water resistant to IPX5 – DO NOT SUBMERGE. If the product has been subjected to excessive moisture/water the warranty may be void.
- This product has a 1 year standard warranty (or extended to 2 years once registered online at WWW.UNILITE.CO.UK/WARRANTY) against manufacturing faults and defects. It does not cover normal wear and tear, modifications, accidental damage or poor maintenance. Unilite standard warranty does not cover disposable batteries that have leaked or the use of incorrect chargers and cables that can damage rechargeable batteries.
- Do not dispose of this device in normal household waste. It must be disposed of via an authorised electrical appliance disposal centre or at your local waste disposal unit.
- Please re-use or recycle packaging responsibly.
- Keep these instructions for future reference or for subsequent possessors.